

The VQuad™ Command Center installation follows the order below:

- VQuad™ Command Center Software Installation
- Hardware Dongle License Installation

Pre-requisites

- PC Requirements – Windows® 7 or Higher OS (32 bit or 64 bit).
- Minimum CPU Requirements – Core i3 to i7 (or equivalent), 4 GB Memory, USB 2.0 Ports.

Step 1: Software Installation

- Plug-in the **USB Installation Stick** (pen drive) to the PC. This is provided with the shipment package by GL Communications.
- Run the **VQuadCommandCenter.exe** executable from the installation USB stick (\VQuad-VQT\VQT030-Command-Center\VQuad-Command-Center-verXX) in **Run as Administrator** mode.
- Follow the on-screen instructions and complete the Command Center software installation.
- The software gets installed in 'C:\Program Files\GL Communications Inc\VQuad Command Center\' directory (or 'C:\Program Files (x86)\GL Communications Inc\VQuad Command Center\' directory in 64-bit Windows® OS) and creates a



shortcut icon on the desktop.





- It is recommended to reboot the system after the software installation.

Step 2: Hardware Dongle License Installation

- Navigate back to root directory in USB installation stick (pen drive) to **GL-Dongle License Installer** folder, right-click on **GLDongleLicenseInstaller_x64.exe** (or **GLDongleLicenseInstaller_x86.exe**) and select **Run As Administrator**.
- Plug the dongle to the USB 2.0 port of your computer. Windows® should install all required drivers automatically. A red light should appear on the dongle indicating that it is functioning correctly from a physical point of view.
- You can verify if the required licenses are installed. Navigate to **C:\Program Files\GL Communications Inc\GLDONGLE** (or **C:\Program Files(x86)\GL Communications Inc\GLDONGLE** for 32-bit version) directory, execute **appl_list.exe** and confirm that the VQT030 license is listed.
- It is recommended to reboot the system after the software installation. For any troubleshooting during hardware dongle license installation, refer to [Installation Instructions for Dongle Programs](#) document.

Step 3: Quick Check-out Procedure

To verify the software installation, perform the following steps:

- The listeners (**GL Listener.exe** and **ASR_Listener.exe**) are started automatically after rebooting the PC. If the listeners are not started automatically, then the users have to invoke the listeners manually from the installation directory (C:\Program Files (x86)\GL Communications Inc\Services) prior to invoking VQuad Command Center application. A GL Listener  icon and ASR_Listener  icon will appear in the task bar.
- To invoke the Command Center application, right-click on the VQuad™ Command Center icon  created on the desktop and choose to **Run as Administrator**.
- Click **Site Engine**  to open the Site script engine.
- Browse to the directory and select the site script to be executed.
- Verify the loaded script commands displayed in the **Script** column.
- Click **Run** button and start executing the script.
- During the script execution, users can view the script events in the **Events** column.

