
MAPS[™] GPRS Gb Interface Emulation over IP/TDM





Overview

GPRS or General Packet Radio Service, was introduced (in the late 90's and early 2000's) to enhance data carrying capabilities of the basic GSM Network. Initially it used the conventional T1 E1 transport and Frame Relay protocol. As the wireless infrastructure evolved towards IP, the migration of 2G systems to IP interface provided many advantages including increased throughput, capacity and economy.

To permit our customers to emulate, test, and verify GPRS Gb over IP, GL offers **MAPS™ GPRS Gb** (Message Automation & Protocol Simulation), a multi-protocol, multi-technology platform that also supports many other protocol families including TDM, IP, ATM and Wireless.

MAPS[™] GPRS Gb supports simulation of **BSS (Base Station Subsystem)** and **SGSN (Serving GPRS Support Node)** network elements over IP transmission protocol. MAPS[™] GPRS Gb also supports **SGSN Pooling** feature to test and verify redundancy, load balancing, and scalability of network. SGSN pooling solution introduces a new routing mechanism which allows a BSC belonging to an SGSN Pool, connect to all SGSNs in that pool. This permits a mobile station to roam freely without a need to change the serving SGSN.

With the purchase of <u>ETH103 - Mobile Traffic GPRS Gb</u>, MAPS[™] GPRS Gb supports Mobile traffic simulation over Gb interface. Currently, this module transmits the pre-canned HTTP file (*.txt) between BSC and SGSN nodes. It multiplexes both signaling and traffic over Gb interface.

For more information, please refer to <u>MAPS™ GPRS Gb Interfaces Emulation</u> webpage.

Main Features

- Simulates SGSN and BSS over GPRS Gb interface.
- Simulates control plane Gb mode.
- Supports SGSN pooling to test and verify redundancy, load balancing, and scalability of network.
- Generates hundreds of Control Signaling (Load Testing).
- Generates and processes NS (Network Service), BSSGP (Base Station Subsystem GPRS Protocol) messages.
- Supported procedures includes Network Service Control, Identity Check, Combined GPRS / IMSI Attach, and Routing Area Update
- Simulates user plane GPRS Gb traffic supporting pre-canned HTTP file transmission.
- Insertion of impairments to create invalid messages.
- Supports customization of call flows and message templates using Script and Message Editors.
- Supports scripted call generation and automated call reception.
- Supports powerful utilities like Message Editor, Script Editor, and Profile Editor which allow new scenarios to be created or existing scenarios to be modified using various protocol messages and parameters.

GL Communications Inc.

818 West Diamond Avenue - Third Floor, Gaithersburg, MD 20878, U.S.A (Web) <u>www.gl.com</u> - (V) +1-301-670-4784 (F) +1-301-670-9187 - (E-Mail) <u>info@gl.com</u>

Testbed Configuration

Test Bed Setup provides options to establish communication between MAPS[™] and the DUT. It includes configuration parameters to be set for UDP configuration. Once the testbed is setup, messages can be transmitted and received over IP network to the DUT. Default profile used to configure MAPS[™] GPRS Gb with SGSN or BSC parameters.

Configurations Emulator Reports Editor Debug Tools	Windows Help	-	. 8
Q 🖉 🛸 🕭 🖡 🗰 📰 🧭 ل 🕯	• • \$ \$		
冲 🔒 🖪			G
Config	Value	✓ Enable	
BSC Configurations			
 Traffic Adapter Index 	3		
- BSC	1		
L BSC 1			
Network Service Parameters			
 Network Service Entity Indicator 	1		
 Network Service Virtual Connection Identifier 	2		
BSSGP Virtual Connection ID	3		
 BSC IP Address 	192.168.13.2		
- Traffic	Enable		
 Traffic IP Address 	192.168.8.2		
 BSC Port 	23001		
 PLMN Identifiers 			
 Mobile Country Code 	901		
 Mobile Network Code 	70		
Lecation Area Identifiers			
 Location Area Code 	10000		
Routing Area Code	1		
- SGSN Parameters			
 SGSN IP Address 	192.168.13.4		
└── SGSN Port	23001		
Cell Identifier	1		
Cell Identity 1			
L Cell Identity	2		
UE Simulation Parameters			
 Type Of UE Simulation 	Profile		
- CSV File Name	\\10.10.1.50\csv\MS_Profi		
L End User Configuration	MS_Profiles.xml	Start Edit	
	Initialisation Errors	Error Events	


Pre-processing Tools

Message Editor - With message editor, users can build a template for each protocol message type. The value for each field may be changed in the message template prior to testing. The protocol fields comprises of mandatory fixed parameters, mandatory variable parameters, and optional variable parameters.


		ACH REQUEST			-		×
*	Direction	Tools Help					
🖻 🔒	8 🗙						
Frame No 1	⊡-Infor ⊜-I	billty Mgmt sage Type mation/Elements MS network capability wake part → Length → GPRS Encryption Algorithm GEA/1 → M capabilities via defasted channels → M capabilities via defast channels → UCS2 support → SS Screening Indicator → SS Screening Indicator → FC feature mode → Extended GEA → GPRS Encryption Algorithm GEA/2 → GPRS Encryption Algorithm GEA/3 → GPRS Encryption Algorithm GEA/3 → GPRS Encryption Algorithm GEA/5 → GPRS Encryption Algorithm GEA/5 → GPRS Encryption Algorithm GEA/5	~	ATTACH REQUEST = 1			
	0000 PDU BVCI 0002 BVC 0004 PDU TLLI 0005 TLL 0005 Pea 0009 Pea 0008 A b 0008 T b 0008 C/R Cell 000C IE	I BssGp Layer Type I value Profile k bit rate cedence(UL-Unidata) it it		0000000 NS-UNITDATA 2 (x0002) 00000001 UL-UNITDATA x781875C0			
Ready	<					NUM	>

Pre-processing Tools (Contd...)

Script Editor - The script editor allows the user to create / edit scripts and access protocol fields as variables for the message template parameters. The script uses pre-defined message templates to perform send and receive actions.



Profile Editor - This feature allows loading profile to edit the values of the variables using GUI, replacing the original value of the variables in the message template. A XML file defines a set of multiple profiles with varying parameter values that allow users to configure call instances in call generation and to receive calls.



Call Generation and Call Reception

In call generation, MAPS[™] is configured for the out going messages, while in call receive mode, it is configured to respond to incoming messages. Tests can be configured to run once, multiple iterations and continuously. Also, allows users to create multiple entries using quick configuration feature.

The editor allows to run the added scripts sequentially (order in which the scripts are added in the window) or randomly (any script from the list of added script as per the call flow requirements). The test scripts may be started manually or they can be automatically triggered by incoming messages.

	/ 🕹 🖉 🕹	š 📁 🍇	🥩 🔮 🗋 🛛	0 0	℃ ^D [™]	2				
5	😑 🔒 🖪 💡		8 क							
r	Script Name	Profile	Call Info		Script Execut	Status	Events	Events Prof	Result	Total Iterations
1	GPRSGbCallControlBSC.gls	MSProfile0001	IMSI,901700000	000638	Stop	GTP-U-MOBILE-TRA			Unknown	1
2	GPRSGbCallControlBSC.gls	MSProfile0002			Start		None		Unknown	1
3	GPRSGbCallControlBSC.gls	MSProfile0003			Start		None	-	Unknown	1
4 5	GPRSGbCallControlBSC.gls	MSProfile0004			Start		None		Unknown	1
5 6	GPRSGbCallControlBSC.gls GPRSGbCallControlBSC.gls	MSProfile0005 MSProfile0006			Start Start		None		Unknown Unknown	1
ь 7	GPRSGbCallControlBSC.gls	MSProfile0007			Start		None		Unknown	1
8	GPRSGbCallControlBSC.gls	MSProfile0007			Start		None		Unknown	1
9	GPRSGbCallControlBSC.gls	MSProfile0009			Start	1	None	1	Unknown	1
0	GPRSGbCallControlBSC.gls	MSProfile0010			Start	1	None	1	Unknown	1
				m						
A/	Save Column Width	efresh Start	Start All Stop			oort Abort All	Find	1		
_			Show Latest	SG	5N		Network	Service Lay	/er ======	
_	Save Column Width -		Show Latest	SG	5N 11:09:37.110.679	0000 PDU BVCI	Type	Service Lay	rer =====	= 000000
_	Save Column Width -	(Show Latest	SG	5N	0000 PDU BVCI 0002 EVC	Type			= 000000
_	Save Column Width		Show Latest	SG	5N 11:09:37.110.675 11:09:37.144.480	34 0000 PDU BVCI 0002 BVCI 0002 BVCI 0004 PDU	rype I BassGp L			= 000000 = = 2 (x00 =
_	Save Column Width	ATTACH REQUE	Show Latest	SG	5N 11:09:37.110.679	44 0000 PDU 13 0004 PDU 13 0004 PDU 13 0004 PDU 15L1	Type Second Second Second Second Second Sype			= 000000 = = 2 (x00 = = 000000
_	Save Column Width	ATTACH REQUE	Show Latest	SG	5N 11:09:37.110.675 11:09:37.144.480	34 33 33 34 35 36 36 37 37 37 37 37 37 37 37 37 37	Type Second Second Second Second Second Sype			= 000000 = = 2 (x00 =
_	Save Column Width	ATTACH REQUE	Show Latest	SG:	5N 11:09:37.110 675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.132	14 13 13 13 13 13 13 14 10 10 10 10 10 10 10 10 10 10	Type I Sype I value Profile I tate	ayer ======		= 000000 = = 2 (x00 = 000000 = x00000 = = 0 (x00
_	Save Column Width	ATTACH REQUE	Show Latest	SG:	5N 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641	4 0000 PDU BVCI 3 0004 PDU 3 0004 PDU 1 LL 0005 TLL 005 TLL 005 Pae 8 0009 Pae	Type I Sype I Sype I value Profile t bit rate redence(UL-Unid	ayer ======		= 000000 = = 2 (x00 = = 000000 = = x00000 = = 0 (x00 =
_	Save Column Width - BSC AUTHENT AUTHENT	ATTACH REQUE	Show Latest	S6:	SN 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.132	44 0000 PDU BVCI 0002 BVC 0002 BVC 0002 C BVC 0004 PDU TLLI 0005 TLLI 0005 TLLI 0005 Peak 0009 Peak 0008 Peak	Type Type Type Type Tvalue Tvofile t bit rate redence (UL-Unid. tt	ayer ======		= 000000 = = 2 (x00 = = 000000 = = x00000 = 0 (x00 =1 =0
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	S6:	5N 11:09:37.110 675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.132	4 0000 Ppu 3 0002 BVC 0002 BVC 0002 BVC 0002 BVC 0004 PpU 12 0005 TL 005 Pa 0005 Pa 0005 Pa 0005 C/R	Type (ype (value brofile s bit rate sedence (UL-Unid tt bit	ayer ======		= 000000 = = 2 (x00 = = 000000 = = x00000 =0 =0
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	SG	SN 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.132	44 0000 PpU BVCI 13 0002 EVCI 13 0004 PpU 13 0005 TLLI 0005 TLLI 0005 TLLI 0008 AB 0008 Pare 0008 Tb 0008 Tb 10 0008 CC 10 0008 CC	Type Ty	ayer ======		= 000000 = 2 (x00 = 000000 = x00000 = 0 (x00 = 0 (x00 =0. =0.
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	SG	5N 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.330 11:09:37.147.390	4 0000 PDU 3 0000 PDU 3 0000 PDU 3 0000 PDU 4 0000 PDU 5 0000	Type (ype (value brofile s bit rate sedence (UL-Unid tt bit	ayer ======		= 000000 = = 2 (x00 = = 000000 = = x00000 =0 =0
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	SG	5N 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.330 11:09:37.147.390	4 0000 PDU 0000 PDU 0002 PDC 0002 PDC 0002 PDC 0002 PDC 0000 PDU 0000	Network Type C Type C value Profile t bit rate redence(UL-Unid tit Identifier Identifier Identifier(CI) yth Krt yth of Cell Iden	ayer ======= ata) ntifier		= 000000 = 2 (x00 = 000000 = x00000 = 0 (x00 =0. =0 =0 = 000010 = 1
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	SG	5N 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.330 11:09:37.147.390	44 0000 PDU BVUI 13 0002 EVUI 13 0004 PDUI 13 0005 TLLI 14 0005 TLLI 15 0005 Pare 10000 B xb 0008 Tb 10000 D000 C stall 0000 C stall 10000 Len 0000 Len 10000 D stall 0000 Len	Vype Vype Value Second Sec	ayer ======= ata) ntifier		= 000000 = 2 (x00 = 000000 = x00000 = 0 (x00 =0 =0 =0 =0 =0 =0 =0 =0
_	Save Column Width BSC	ATTACH REQUE	Show Latest ST HERING REQ HERING RESP PT TE Request	SG	5N 11:09:37.110.675 11:09:37.144.480 11:09:37.144.641 11:09:37.147.330 11:09:37.147.390	4 0000 PDU 0000 PDU 0002 PDC 0002 PDC 0002 PDC 0002 PDC 0000 PDU 0000	Vype I Vype I Value Vofile I value vofile I value Vofile Vofi	ayer ======= ata) ntifier		= 000000 = 2 (x00 = 000000 = x00000 = 0 (x00 =1 =0. =0. = 0.00010 = 1

Figure: Call Generation


) 🗐 🖄	۵ 🗞 🖡		a 🗭	%]	6	ò	£ 🖳	0						
No Script Nar	me	Profile		Call Info		S	Cript Execution	1	Status		Events	Events Pro	Results	
2 NS_F	SessionInit.gls RESET_Recv.gls						Stop Stop				None None		Unknown Pass	
3 GPRSGE	CallControlSGSN.g	als MSP	ofile0001	IMSI,9017	0000000	06	Completed	C	MM-DE	REGISTERED	None		Pass	
	op All Abort	Abort All		Records 「 now Latest	Select A	active (Call 🥅 Auto T	rash	Trast	1				
DUT					h	MAPS			-		Fir	id		
	A	TTACH RE	UEST			11:0	09:37.143.1238	3		e Netwo	ork Service 1	ayer =====	====== = = 00000000 N	IS-1
4	AUTHENTIC	ATION AND	CIPHERIN	G REQ		11.0	09:37.143.3959	1					= = 2 (x0002)	
	AUTHENTIC	TION AND	CIPHERING	RESP			09:37.145.7982			:==== BssGp >e	Layer ====		= = 00000001 U	L-U
		ATTACH AC	CEPT				09:37.145.9872		Е	7alue Dfile			= = x0000003	
	A	TTACH COM	PLETE				09:37.148.4518			pille pit rate lence(UL-Ur			= = 0 (x0000) =100 R	- 4
	Activa	te PDP Con	ext Reques	t						tence (ob-or	iidaca)		=0 R =0 S	ad:
	Activ	ate PDP Con	text Accept				09:37.148.5368			.t lentifier			=0 S	
•		ate PDP Cor		st			09:37.148.7416			entifier(CI 1 Ext	.)		= 00001000 C = 1 E	
		/ate PDP Co					10:37.157.2824			1 of Cell I 11 Identif			= .0001000 (= 1 E	
-						11:1	10:37.157.4628	3	-				= 901	_

Figure: Call Reception

MAPS[™] GPRS Gb Procedures


Routing Area Update Procedure

MAPS[™] GPRS Gb configured as BSC sends a routing area update request when a GPRS-attached MS detects that it has entered a new RA, or when the periodic RA update timer has expired, or when the MS has to indicate new access capabilities to the network or, when a suspended MS is not resumed by the BSS



Network Service Control Procedure


MAPS[™] GPRS Gb configured as BSS uses this Network Service Control test procedure to check end-to-end communication with its peer entity (SGSN) on NS-VC.




MAPS[™] GPRS Gb Procedures (contd..)

IMSI Attach/Detach Procedure

MAPS[™] GPRS Gb configured as BSC allows a GPRS attach request to be made to the SGSN. The SGSN sends Identity Request (Identity Type) to the MS. The MS responds with Identity Response (Mobile Identity).



Supported Protocols and Specifications



Supported Protocols	Standard / Specification Used
BSSGP	3GPP TS 08.18 V8.10.0 (2002-05)
LLC	3GPP TS 04.64 V8.7.0 (2001-12)
NS (Network Service)	GSM 8.16 (ETSI TS 101 299 V8.0.0)
GMM	3GPP 24.008
SMG (GPRS Session Mgmt)	3GPP TS 24.008 V5.16.0 (2006-06) (Release 5)
SNDCP	3GPP TS 04.64 V8.7.0 (2001-12)

Buyer's Guide

Item No	Product Description
<u>PKS131</u>	MAPS™ Gb Emulator over IP
<u>ETH100</u>	Mobile Traffic - PacketCheck™
<u>ETH101</u>	MobileTrafficCore - GTP
<u>ETH102</u>	MobileTrafficCore - Gateway
<u>ETH103</u>	MobileTrafficCore - Gb
<u>PKV100</u>	PacketScan [™] - All IP Protocol Analyzer

Note: PCs which include GL hardware/software require Intel or AMD processors for compliance.

For more information, please refer to <u>MAPS[™] GPRS Gb Interfaces Emulation</u> webpage.



818 West Diamond Avenue - Third Floor, Gaithersburg, MD 20878, U.S.A (Web) <u>www.gl.com</u> - (V) +1-301-670-4784 (F) +1-301-670-9187 - (E-Mail) <u>info@gl.com</u>